

Functionality	Standard	Prime	Enterprise
Secure Remote Cloud Configuration			
Individual Device Configuration	✓	✓	✓
View / Edit Device Configuration		✓	✓
Clear Device Configuration	✓	✓	✓
Remote Reboot	✓	✓	✓
Restore to factory defaults	✓	✓	✓
Export Device List	✓	✓	✓
Group Device Configuration	✓	✓	✓
View / Edit Group Configuration	✓	✓	✓
Export Group Device List	✓	✓	✓
Group NetCloud OS Updates	✓	✓	✓
Copy Configuration to Group	✓	✓	✓
WAN Network Interface Configuration	✓	✓	✓
View / Edit Network Interface Configuration	✓	✓	✓
Export Network Interface List	✓	✓	✓
Modem Configuration	✓	✓	✓
Modem Firmware visibility & management	✓	✓	✓
Modem Firmware Updates	✓	✓	✓
Auto & Manual Modem Carrier Switching	✓	✓	✓
Scheduler	✓	✓	✓
NetCloud OS Updates	✓	✓	✓
Advanced Enterprise Routing		✓	✓
Linked Router Management (LLDP)		✓	✓
Remote Connect		✓	✓
Connect to Device UI		✓	✓
Console (CLI)		✓	✓
Out-of-Band Management		✓	✓
LAN Manager – 3rd Party Devices		✓	✓
Advanced Enterprise Routing		✓	✓
OSPF		✓	✓
BGP		✓	✓
RIP		✓	✓
VRRP		✓	✓
STP		✓	✓
NHRP		✓	✓
Advanced VPN & Tunneling		✓	✓
OpenVPN (SSL VPN)		✓	✓
L2TP		✓	✓
NEMO / DMNR Primary		✓	✓
NEMO / DMNR Failover		✓	✓
Linked Router Management (LLDP)		✓	✓
Application Aware Firewall			✓
Application Aware QoS			✓

Functionality	Standard	Prime	Enterprise
Real-Time Diagnostics / Troubleshooting			
Basic Real-Time Device Status	✓	✓	✓
Advanced Real-Time Device Status	✓	✓	✓
Basic Network Interface Status	✓	✓	✓
Advanced Network Interface Status		✓	✓
Ping	✓	✓	✓
Traceroute	✓	✓	✓
Speed Test per WAN Interface	✓	✓	✓
Device Log	✓	✓	✓
Debug Diagnostic Data Log	✓	✓	✓
User Activity Log	✓	✓	✓
Rogue AP Detection	✓	✓	✓
WiFi Site Survey	✓	✓	✓
Visibility / Analytics			
WAN Network Dashboard	✓	✓	✓
Group Dashboard	✓	✓	✓
Device Dashboard	✓	✓	✓
LAN Client Dashboard		✓	✓
WAN Data Usage	✓	✓	✓
Modem / Carrier (Pooled) Data Usage Analytics		✓	✓
WAN Uptime Analytics		✓	✓
LAN Client Analytics		✓	✓
Application Traffic Analytics			✓
Remote Connect / Out-of-Band Management			
Securely Connect to Device User Interface in any network architecture		✓	✓
Securely Connect to Device Console (CLI) in any network architecture		✓	✓
Out-of-band Management for access to non-Cradlepoint devices with console port		✓	✓
LAN Manager for access to LAN connected 3rd Party Device User Interfaces		✓	✓
GeoView Location Services			
Device map location with quick view status		✓	✓
Geo-Fence alerting for physical security		✓	✓
Alerts / Reports			
Alert Management	✓	✓	✓
Network, Group, Device reporting	✓	✓	✓
Activity Audit Log	✓	✓	✓
Security			
Activity Audit Log	✓	✓	✓
URL Content Filtering			✓
Threat Intelligence			✓
Web Reputation			✓
IPS / IDS	Optional	Optional	Optional
NetCloud Perimeter	Optional	Optional	Optional

Functionality	Standard	Prime	Enterprise
Extensibility			
Custom business applications running at the edge with Router SDK	✓	✓	✓
RESTful API	✓	✓	✓
Accounts & Users			
Manage Users	✓	✓	✓
Manage Permissions	✓	✓	✓
Active Directory Domain Authentication (Federated ID)	✓	✓	✓
Access all Cradlepoint Services with Single-Sign-On	✓	✓	✓